

# WEROF-05 WALL CONTROL

## SPECIFICATION and INSTRUCTION SHEET

**DESCRIPTION:** One Fan(no light) Only, 4 Speed-Rotary Control

**ELECTRICAL SPECS:**220~240 Volts, 50Hertz, Fan 100W watt,

2 Wire Installation

### How to Wire and Operate WEROF-05 Wall Control

**NOTE:** If fan or supply wires are different colors than indicated, have this unit installed by a qualified electrician.

1.Installing Wall Control(Figures 1&2):

With electrical power still disconnected, remove the existing wall plate and switch.

Make wiring connections with wire nuts as shown in Figure 1.

—One brown wire from wall control unit to red/brown (hot supply).

—One brown wire from wall control unit to brown wire leading to ceiling outlet box.

Attach wall control unit to outlet box using the two screws.

Attach wall plate to the switch control front.

Restore electrical power.




Figure 1

#### ⚠ WARNING

To avoid possible fire or shock, make sure that the electrical wires are completely inside the outlet box and not pinched between the wall plate and the wall.

#### ⚠ WARNING

Check to see that all connections are tight, including ground, and that no bare wire is visible at the wire connectors, except for the ground wire. Do not operate fan until the blades are in place. Noise and fan damage could result.

2.Operating & Using Wall Control:

**NOTE:** Set pull chain to high speed before using the wall control. You can now use your speed control to select any of the 4-speeds plus OFF.

.4th Position-high fan speed

.3rd Position-medium fan speed

.2nd Positon-low fan speed

.1st Position-lower fan speed

.OFF Position-fan off




Figure 2