LED SERIES OPERATION INSTRUCTIONS

SL-LED-250/SL-LED-330/SL-LED-550

Note: Before starting of installation please read this leaflet and keep it carefully.

Main structures and application fields

The body of the lamp is made of ABS.

This product can be used on a bookshelf, the base of a pelmet & the inside of a bookcase.

Main parameter

Item	Rated voltage/V	Rated power/VA	LED numbers	Protection
SL-LED-250	240V	2.7W	47LEDS	CLASS:II.IP20
SL-LED-330	240V	3.6W	65LEDS	CLASS:II IP20
SL-LED-550	240V	6.8W	121LEDS	CLASS:II IP20

Installation direction maintenance

- 1. This product should be installed by a qualified electrician
- 2. Turn off the power before installation.


Installation steps (please see the drawings)

- 1. Making a hole as per dimension of the lamp.
- Fixing the part (3) in the hole, then put the screws (1) through the installing board (A/B)
 (A: install on flat surface; B: install on corner) and install on the surface of the lamp.
 If required these products can be linked.
- Make sure the product can be installed steadily, then connect wire (4) to the socket and connect the plug to the power supply.
- 4. Turn on the power.

Safety directions

- The productions are double insulated and fixing hole must be flat.

 Make sure the minimum distance between the lamp and the fixing surface is less than 10mm.
- 2. The installation of the lamp can be seen as drawing (2) or (3).
- The lamp can be moved up and down along the branch.If linking as picture (2), Be sure the branches are in a line.
- 4. If there is any damage to this product when installing, please do not use.



Dimension1 SL-LED-250



Dimension SL-LED-330



Dimension3 SL-LED-550

