


User Manual

for Kinetic Wall Switches

CUL 40031 65CUL 40034 65CUL 40032 65CUL 40035 65CUL 40033 65CUL 40036 65


v1

A. What is in the box ?




B. Specifications


Dimensions:



Power Source: Self Powered (Kinetic) Radio Frenquency: 433 MHz Switching Type: Push Switch Dimming Type: Push Selected Only available on 2 Gang Switch



IP Rating: IP65 Body Material: Polycarbonate




Transmission Range: Outdoor 150m (no barrier) Indoor 25m (plaster board; drywall) Indoor 12m (concret, glass walls) (Range may vary depending on surrounding situation)



C. Installations - Suitable for Indoor Use only.

1. Screw Installation

ⓐ Remove front cover;




© Reinstall front cover;




Inserting a coin into the switch gap and twisting it, can help to open the cover.


(b) Fix to back box;





(d) Installation Completed.






2. Surface Installation


(a) Remove sticker cover;



© Clean the surface



(b) Apply to the switch;



d Attach the switch to surface.

