
## **Microwave Movement Sensor**

This product is fitted with a microwave movement sensor. Please see below detailed operating instructions.

#### **Technical Specifications:**

<b>A</b> 11 11				
Operating voltage		220 ~ 240V AC 50/60Hz		
Rated load		400W (Capacitive load) 800W (Resistive load)		
Stand-by power		≤0.5W		
Ceiling mounted height: 3m		100% / 75% / 50% / 25% / 10%		
Sensitivity	Ceiling mounted height: 6m*	100% / 75% / 50%		
	Wall mounted height: 2m	100% / 75% / 50% / 25% / 10%		
Hold-time		5s / 30s / 90s / 3min / 20min / 30min		
Daylight sensor		2Lux / 10Lux / 25Lux / 50Lux / Disable		
Microwave frequency		5.8 GHz ±75MHz		
Transmitting power		1mW Max.		
Detection range	Ceiling mounted height: 3m	3- 6m (radius )		
	Wall mounted height: 1.5-2m	12-15m		
Detection angle		360º (Ceiling) / 120º (Wall)		
Working temperation	ature	$-20^{\circ}C \sim 60^{\circ}C$		
*50% 75% 100% det	action consitivity	vis workable when installed at 6m mounting beight. Only 10% 25%		



Instruction leaflet


# Forca EM, MW & CCT LED Bulkhead 77902



\*50%, 75%, 100% detection sensitivity is workable when installed at 6m mounting height. Only 10%, 25% sensitivity is not able to detect motion signal.


#### Settings:

1. Sensitiv Sensitivity of combination applications	can be n on th					0	2
I –100%			1	2	3		
II – 75%	, m	Ι				100%	
III – 50%	Å	II	0			75%	
IV - 25%	0	III		0		50%	
V- 10%		IV	0	0		25%	
		V	$\bigcirc$	0	0	10%	



3. Daylight sensor
Different daylight threshold can be preset on I
switches. Light will always turn on upon mov

DIP vement if daylight sensor is disabled.



on light once motion is detected regardless of ambient light level.

#### Trouble shooting:

Malfunction Cause Remedy	Cause	Remedy
	Incorrect light-control setting selected	Adjust daylight threshold setting
The light will not come on	Faulty lamp	Replace lamp
	No power supply	Check power to sensor
The lamp is always on	Continuous movement in the detection zone	Check detection area setting
	The sensor is not mounted for reliably detecting movement	Securely mount enclosure
The lamp is on without any identifiable movement	Movement occurred, but not identified by the sensor (Movement behind wall, movement of small object in immediate lamp vicinity etc.)	<ol> <li>Reduce sensitivity.</li> <li>Check the movement behind walls to avoid facilities such as water pipe, fan, which may mis-trigger the sensor.</li> </ol>
The lamp will not work despite movement	Rapid movements are being suppressed to minimize malfunctioning or the detection radius is too small.	Check detection area setting

#### **Care and Safety**

- We recommend cleaning with a soft dry cloth. Do not use solvents or abrasive cleaners as these could damage the finish.
- · For your safety, always switch off the power supply before cleaning.

CE

V4 15/01/2021

. . . . .



Thank you for purchasing this light fitting. Please read the instructions carefully before use to ensure safe and satisfactory operation of this product. Please retain these instructions for future reference.

#### Warning

#### This product is Class 2 (Double insulated) and must not be earthed.

Please read these instructions carefully before commencing any work.

This unit must be fitted by a competent and gualified electrician.

Install in accordance with IEE Wiring regulations and current Building Regulations.

To prevent electrocution switch off at mains supply before installing or maintaining this fitting. Ensure other persons cannot restore the electrical supply without your knowledge. If you are in any doubt, please consult a qualified electrician.

This light fitting should be connected to a circuit with a 30mA RCD fitted.

If replacing an existing fitting, make a careful note of the connections.

This product contains non-replaceable parts and cannot be serviced. If damage occurs the part should be scrapped.

Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your local authority or retailer for recycling advice.

#### **Technical data**

Supply Voltage:	240V~, 50 Hz	Lumens: 120Lm in EM mode Duration: 3 hours (180 Minutes)	Change over time: Approximately 1s Battery Specification: LifePO4 3.2V 1500mAh
Bulb Type:	18W LED module CCT, 3000K/4000K/6500K	Operating Temperature: 0°C - 50°C Maximum Operating Humdity: 90%	Battery Charge Time: 24 Hours Battery warranty: 2 years
CE	Conformity with all relevant EC Directive requirement	nts.	
	Waste electrical products should not be disposed of Please recycle where facilities exist. Check with you local store for recycling advice.		
	The power supply is Double Insulated and does not	t require connection to an Earth ci	rcuit.
	This product is not suitable for dimming.		
IP65	This product is rated at IP65.		

#### Layout

- Plan the desired layout of this fitting carefully, ensuring the cables will reach the distance between the junction box and the light fitting.
- · Avoid locating any cables in positions that would cause a hazard. Position cables and junction boxes (not supplied) away from areas where they may be at risk from being cut, trapped or damaged.
- The mains supply cable must have a minimum cross sectional area of 1.0mm<sup>2</sup>.
- · Cables must be protected using suitable conduit or plastic trunking.
- . The products can be wall or ceiling mounted. If wall mounting ensure that the power supply is at the bottom.

#### Individual casings

The following individual casings are available for purchase separately. 77904 : White plain 77907 : Grey plain 77910 : Black plain 77913 : Chrome plain 77905 : White eyelid 77908 : Grey eyelid 77911 : Black eyelid 77906 : White arill 77909 : Grey grill 77912 : Black grill

Installation

Existing fittings must be completely removed before installation of a new product. Before removing the existing fitting. carefully note the position of each set of wires.


- Remove the 4 fixing screws and detach the shade. Keep safe for refitting later.
- Hold the product in place and mark the position of the holes. Ensure the wall is capable of holding the weight of the product, or if fitting to a ceiling, ensure there is a joist at the point of fixing to support the weight of the product.
- Knock out the chosen fixing holes.
- · Fix into position. Take care to avoid damaging any concealed wiring and pipes. The correct fixings should be used for brick, cavity walls or plasterboard.
- · Pierce a hole in the grommet, and pull the cable through.
- · Wire as detailed below.

# Wirina

- This product is double insulated and must not be earthed. If there are any incoming ex with good quality insulation tape. This is to ensure earth continuity throughout your p
- · Having correctly identified the wiring from your existing light fitting, connect to the qu supplied link cables where necessary.



#### Maintained (Unswitched) Wiring: The product is on permanently and comes on during a power failure



## Check that...

- · You have correctly identified the wires.
- · The connections are tight.
- No loose strands have been left out of the connection block

#### Commissionina

- Ensure that the screws and cable entry points are sealed to maintain the IP rating of the product.
- Refit the shade, ensuring that the seals are correctly located.
- · Gently push your chosen casing onto the shade until it clips in place.
- Replace fuse or circuit breaker and switch on. Your light is now ready for use.

#### Fitting/replacing bulbs

This system contains non-replaceable parts and cannot be serviced. If damage occurs the part should be scrapped.

#### **CCT Function**

 This colour is changeable between 3000K-4000K-6500K, using the switch inside the product.

BCOOL WHITE4000KCDAYLIGHT WHITE6500K	Α	WARM WHITE	3000K
C DAYLIGHT WHITE 6500K	B	COOL WHITE	4000K
	C	DAYLIGHT WHITE	6500K

perty. k fit connection block in the following w	vay, using the
Non-Maintained Wiring: The product i and comes on during a power failure	is normally off
SUPPLY	LIGHT FITTING
PERMANENT LIVE	BROWN (L)
NEUTRAL	BLUE (N)
Maintained (Switched) Wiring: The pr	
light - switch on/off, light turns on/off. Comes on during a power failure.	
	LIGHT FITTING
Comes on during a power failure.	
Comes on during a power failure.	