




INS CZ 31740 - C



Please take time to read this leaflet carefully and retain it for future reference.






The light keeps off during daytime even when movement is detected. (Ambient lux level is above preset daylight threshold)



With movement and insufficient ambient lux level, the light is triggered on by the detector.



If there is no more movement, the light dims to stand-by level after hold-time.



The light turns off automatically after stand-by time.

# Settings

### 1. Sensitivity

Sensitivity can be adjusted by selecting the combination on the DIP switches for different applications.

1- 100% 11 - 50%

• <b>•</b>		1	
	I		100%
	II	0	50%

#### 2. Hold-time

Hold-time refers to the time period that the light remains 100% on if no more movement is detected.

1 - 5s 11 - 90s

III – 3min IV - 10min

		2	3	
•	I	•	•	5s
Ä	II	•	0	90s
ŏ	III	0	•	3min
	ΙV	0	0	10min

# 3. Daylight sensor

Different daylight threshold can be preset on DIP switches. Light will always turn on upon movement if daylight sensor is disabled.

I – Disable 11 – 50Lux

III – 10Lux IV – 2Lux

		4	5	
	Ι	•	•	Disable
	II	•	0	50Lux
	III	0	•	10Lux
	IV	0	0	2Lux

### 4. Stand-by time

This is the time period that the light remains at a low level before it is completely turned off.

1 – Os

11 – 10s III – 10min

 $IV - +\infty$ 

		6	7	
5	Ι	•	•	Os
	II	•	0	10s
	III	0	•	10min
	TV			1.00

### 5. Stand-by dim level

Light can be dimmed to different levels after hold-time.

1- 10%

11 - 30%



# Detection pattern

