
Wiring

Having correctly identified the wiring from your existing light fitting, connect to the approved outdoor junction box(not supplied) in the following way:



Check that...

You have correctly identified the wires. The connections are tight. No loose strands have been left out of the connection block.

Technical data

Supply Voltage: 220-240 $V\sim$, 50 Hz

Bulb 114575----2.6W LED module CCT, 3000/4000/6500K 114576----2 x 2.3W LED module CCT, 3000/4000/6500K 114577-----4 x 1.4W LED module CCT, 3000/4000/6500K

This product contains a light source of energy efficiency class **F**.



Non-replaceable light source



Non-replaceable control gear



Conformity with all relevant UKCA Directive requirements.



Conformity with all relevant EC Directive requirements.



This product is Class 1, must be connected to earth.



Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority or local store for recycling advice.



This product is not suitable for dimming.



This product is rated at IP67.



This product is rated at IK10.

Care and Safety

We recommend cleaning with a soft dry cloth. Do not use solvents or abrasive cleaners as these could damage the finish. For your safety, always switch off the power supply before cleaning.

For further information, please visit https://www.lighting-info.co.uk/114575

V1 24/03/2025


UK Manufacturer: BH17 7BY **EU Manufacturer:** Brilliant AG, Brilliantstrasse 1, D-27442 Gnarrenburg



Instruction manual

Marka CCT

114575, 114576, 114577





Thank you for purchasing this light fitting. Please read the instruction carefully before use to ensure safe and satisfactory operation of this product. Please retain these instruction for future reference.

Warning

This is a Class 1 product and must be earthed.

Please read these instructions carefully before commencing any work

This unit must be fitted by a competent and qualified electrician.

Install in accordance with the IEE Wiring regulations and current Building Regulations.

Check the pack and make sure you have all the parts listed.

To prevent electrocution switch off at the mains supply before installing or maintaining this fitting. Ensure other persons cannot restore the electrical supply without your knowledge. If you are in any doubt, please consult a qualified electrician.

This light fitting should be connected to a fused circuit.

If replacing an existing fitting, make a careful note of the connections.

This system contains non-replaceable parts and cannot be serviced. If damage occurs the part should be scrapped.

Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your local authority or retailer for recycling advice.

Layout

Plan the desired layout of these fittings carefully, ensuring the cables will reach the distances between the each light fitting. Avoid locating any cables in positions that would cause a hazard. Position cables and outdoor rated junction

boxes (not supplied) away from areas where they may be at risk from being cut, trapped or damaged.

We recommend that you use H07RN-F specification cable which is an outdoor grade, rubber sheathed cable.

The mains supply cable must have a cross section area of 1.0mm².

Cables must be protected using suitable conduit or plastic trunking.

The product is designed to be fitted horizontally and vertically in decking, walls, steps etc. If the product is ground mounted, the product must be installed on the concrete and must not be installed into soil.

Installation

Existing fittings must be completely removed before installation of a new product. Before removing the existing fitting, carefully note the position of each set of wires.

Note that the switch is turned off before installation.

After deciding the layout of the light fittings ensure that the cables are long enough to connect to desired positions.


- Mark the position of the mounting holes and drill. Then use a hammer to drive the expansion screws into the holes, and use an allen driver to unscrew the screws.
- Loosen the screws and separate the base from the lamp cover if you need to change the color temperature (the default color temperature is 4000K).
- Choose your preferred colour by using the CCT Switch.
- · Refit the base into the cover with screws set aside earlier
- Align the mounting holes on the lamp with the expansion screws on the mounting surface, and then use the screws to firmly fix the lamp on the mounting surface.
- Replace fuse or circuit breaker and switch on. Your light is now ready for use.


Ground Installation Guide







* Product images may vary.











This product is colur changing and can be either 3000K or 4000k or 6500K. Choose your preferred colour by using the CCT switch.

Note: Before you change the colour every time, please turn off the power switch for safety.

5.









77

1 0-2 5mm²